
INSTALLATION AND FIXING

FIXING

manau	iator is supplied with:	
4 x Wall	Brackets 1 x Bleed Valve	
4 x Wall	Hooks 1 x Blank Plug	
4 x Brac	ket Inserts	
Step 1:	You will see a small indentation on the underside of one of the collectors and this indicates where the diverted is situated. When fitting the radiator the indentation must be placed at the bottom to ensure that the water will flow correctly.	
Step 2:	The fixing position for the top 2 brackets are measured at 40mm in from either end of the top collector and measured down 55mm. To correctly mark the bottom bracket fixing position we suggest you mark the, fix and level the top 2 brackets first.	
Step 3:	Hang the radiator, ensuring that is vertically level and manually hold the bottom brackets into position whilst marking.	
Step 4:	Fit the bleed valve and the plug into the holes provided. Making sure not to over tighten	
Step 4: Step 5:		

ADDITIONAL INFORMATION

If you are fixing your radiator to a stud wall, you should place the radiator in the desired position and hold up the back plate in position and mark through the fixing holes to a secure position.



Testing authority Max operation pressure Max working temperature % Flow and return 8 Bar EN442 6 Bar 90c