



Check the bearing surface for load-carrying capacity. For safety reasons wall plugs and screws aren't delivered. Contact your dealer for the right type of screws / plugs. Observe special requirements for e.g. public buildings.



Head Office


The Radiator Centre, 7 Holywell Hill, St Albans, AL1 1EU

Tel: 01727 840344



Wallbracket (2x)

ZV-1<12 buizen  
ZV-1<12 Tubi



ZV-1/ZV-2<12 buizen  
ZV-1/ZV-2<12 Tubi

ZV-2<12 buizen  
ZV-2<12 Tubi

