






MONTAGEVOORSCHRIFT
MONTAGE-ANLEITUNG

MOUNTING INSTRUCTIONS
INSTRUCTIONS DE MONTAGE

INSTRUCCIONES DE MONTAJE

BRYCE PLUS

Voor uw veiligheid:borgaat gebruiken
Pour votre sécurité:utiliser le trou de fixation
Für Ihre Sicherheit:das Sicherungsloch anwenden
For your security:use the locking hole



Werkdruk : Max. 10 bar
Betriebsdruck : Max. 10 bar
Pression de service : Max. 10 bar
Operating pressure : Max. 10 bar

L	375	450	525	600
---	-----	-----	-----	-----

H	1600	1800	2000	2200
---	------	------	------	------