


Vela Radiator

TECHNICAL SPECIFICATIONS FOR YOUR VELA RADIATOR




Wall to Pipe Centres=55mm	Wall to Front Face=90mm
---------------------------	-------------------------



Materials	Aluminium
Connections	½ Flow and return
Test pressure	9 Bar
Testing authority	EN442
Max operation pressure	6 Bar
Max working temperature	90c

These can be cleaned using a soft damp cloth with a non-abrasive cleaning product

INSTALLATION AND FIXING

FIXINGS This radiator is supplied with: 4 x Wall Brackets 8 x Bracket Inserts		
Step 1:	Offer up the radiator in the desired position and mark the position of the bracket fixing on the wall. Ensuring that they are level. Using a suitable tool drill holes for the wall fixings.	 
Step 2:	Using the fixings provided, fix the wall brackets to the wall.	
Step 3:	Place the plastic inserts onto the wall brackets.	
Step 4:	Offer up the radiator onto the wall brackets. Making sure that the square cut outs on the back of the radiator line up with brackets. Slot the radiator into the inserts and ensure it is securely located.	
Step 5:	The radiator can now be connected to the central heating system and bled via the bleed valve.	

Head Office

The Radiator Centre, 7 Holywell Hill, St Albans, AL1 1EU

Tel: 01727 840344

St Albans. Brighton. Islington.
Clapham. Leamington Spa.