






Arcadia Vertical Designer Radiator

INSTALLATION AND FIXING

<p>FIXINGS This radiator is supplied with: 4 x Wall Brackets 8 x Plastic Inserts 4 x Expanding Bolt Fixings</p>		
<p>Step 1:</p>	<p>Offer up the radiator and mark the position of the bracket fixing on the wall, ideally 1 bar from each end, ensuring that they are level. Using a suitable drill bit, drill holes for the wall fixings.</p>	
<p>Step 2:</p>	<p>Place plastic inserts onto the brackets</p>	
<p>Step 3:</p>	<p>Offer up the radiator onto the wall brackets and check if level. There is the facility for fine adjustment via the slotted hole in the bracket.</p>	
<p>Step 4:</p>	<p>The radiator can now be connected to the central heating system and bled via the bleed valve</p>	

<p><u>HORIZONTAL BRACKETS</u> The box will contain: 2 x Pairs of Horizontal Wall Brackets</p>		
<p>Step 1:</p>	<p>Offer up the radiator and mark the position of the bracket fixing on the wall, ideally 1 bar from each end, ensuring that they are level. Using a suitable drill bit, drill holes for the wall fixings.</p>	
<p>Step 2:</p>	<p>Offer up the radiator onto the wall brackets and check if level. There is the facility for fine adjustment via the slotted hole in the bracket.</p>	
<p>Step 3:</p>	<p>The radiator can now be connected to the central heating system and bled via the bleed valve</p>	

ADDITIONAL INFORMATION

If you are fixing your radiator to a stud wall, you should place the radiator in the desired position and hold up the back plate in position and mark through the fixing holes to a secure position.

Head Office

The Radiator Centre, 7 Holywell Hill, St Albans, AL1 1EU

Tel: 01727 840344

St Albans. Brighton. Islington.
Clapham. Leamington Spa.

Arcadia Vertical Designer Radiator

Standard Brackets

Wall to Pipe Centres=65mm	Wall to Front Face=105mm
---------------------------	--------------------------

Horizontal Brackets - Single

Wall to Pipe Centres=26mm	Wall to Front Face=65mm
---------------------------	-------------------------


Horizontal Brackets - Double

Wall to Pipe Centres=61mm	Wall to Front Face=99mm
---------------------------	-------------------------

Standard	F = Flow	P = Plug
Connections 1/2"	R = Return	V = Vent


Pipe centres Vertical = radiator width + valves | Horizontal = radiator width + 45mm

Wall to front face = 105mm
Wall to pipe centre = 65mm



Single Vertical


Wall to front face = 105mm
Wall to pipe centre = 65mm



Double Vertical

Single
Wall to front face = 65mm
Wall to pipe centre = 26mm

Double
Wall to front face = 99mm
Wall to pipe centre = 61mm



Additional Horizontal Brackets

Head Office

The Radiator Centre, 7 Holywell Hill, St Albans, AL1 1EU

Tel: 01727 840344

St Albans. Brighton. Islington.
Clapham. Leamington Spa.